

Titan^{neo} Input Panel



The Input Panel provides a Lo-z XLR Microphone Input (1/4" Phone or XLR) with Mic Volume Control, Dual RCA Line Input with volume control and Dual RCA Line Output, Treble & Bass Controls, Master Volume Control. Voice Priority Circuit and Battery Level Indicator

Specifications

Audio Input	XLR-TRS Balanced Mic
Audio Output	Line Level, Dual RCA
Controls	Line Level, Dual RCA Master Volume, Treble, Bass Mic Vol., Line Input Vol., Voice Priority Switch
Voice Priority Control	On/Off
Attack time	<.1mS
Release time	3 seconds
Attenuation	<-26dB

Features

Simultaneous mixing with the microphone inputs
 Plug-In microphone Lo-z, XLR or phone plug connection
 Treble and bass controls
 Dual line input (RCA) with volume control
 Dual line output (RCA)
 Voice Priority Switch
 4 LED battery level indicator
 AC Operable without batteries being fully charged

Charging Functions

Charging	LEDs Light in Sequence
Fully Charged	Only top green LED will light

Battery Level Indication

Top LED (Green) lights:	80–100% charged
Second LED (Green) lights:	50–80% charged
Third LED (Yellow) lights:	20–50% charged
Bottom LED (Red) lights:	0–20% charged

Internal battery requires 8 – 10 hours to fully charge